

8.1 Microcontroller architecture

Name: _____ Class: _____ Date: _____

Total: 22 marks

KEY WORDS microcontroller • memory-mapped register

Objective

Size memory maps from address widths, trace the fetch–decode–execute cycle, and read a register-level datasheet description – every answer checked against bit widths and address bounds.

1 Key knowledge and worked examples

■ The memory map is arithmetic

N address lines address 2^N locations. A region spans from base to base + size – 1; regions cannot overlap, and the top address bits often select the region.

■ Worked example: placing two regions

Flash 128 KB at 0x0000_0000; SRAM 32 KB at 0x2000_0000. Flash spans 0x0000_0000–0x0001_FFFF ($2^{17} = 131\,072$ bytes); SRAM spans 0x2000_0000–0x2000_7FFF (2^{15}). Check: 128 KB needs 17 address lines ✓ (widths match the sizes); the regions' top bits differ (0x000... vs 0x200...) so they cannot overlap ✓; and the decoder can simply compare address bits [31:29] – the map was chosen to make the decoding cheap.

■ The cycle and the register file

Fetch (PC → instruction), decode (control unit), execute (datapath), PC advance or jump. The **register file** holds the working set: 16 registers of 32 bits in a classic embedded core – the fastest storage the programmer names directly.

2 Practice

2.1 How many address lines for 2 KB? For 1 MB?

[2]

2.2 A peripheral's 32-bit register has bits [7:4] as a field. What range of values fits, and what mask extracts it? [3]

2.3 A 4 GB address space places peripherals in the top 16 MB. Give the base address and the number of bits that must be checked to recognise it. [3]

3 Exam-style questions

3.1 A microcontroller has 512 KB flash at 0x0000_0000 and 96 KB SRAM at 0x2000_0000.

Give each region's end address (exact hex). Then a third region: peripherals mapped in a 64 KB window at 0x4000_0000 – give its range and state, for each of the three regions, how many address lines the region itself uses and which single bit pattern in the top 4 bits [31:28] identifies it. Verify no two regions overlap. [7]

3.2 A 16-bit timer/counter’s register map: CR1 (control), SR (status), CNT (count), ARR (auto-reload) – each 16 bits at consecutive word addresses from 0x4000_1000.

Write the C declarations mapping these registers (volatile pointers). Then: the ARR is loaded with 4999 and the counter starts at 0 – state the number of counts per full period and why the period register is often “N–1”. Finally, compute the timer’s output frequency if the counter’s input clock is 8 MHz and the prescaler register (also 16-bit) is set to 7 (the divider is prescaler + 1). [7]
