9.5 Joints and gears

Name: _____ Class: _____ Date: _____ **Total: 14 marks**

KEY WORDS bolted joint • preload • spur gear • module • Lewis form factor

Objective

Preload a bolted joint and find the bolt's share of an external load, its load factor and the separation load; then check spur-gear teeth in bending with the Lewis equation.

1 Key knowledge and worked examples


Bolts and gear teeth

- **Bolted joint** : **preload** $F_i = 0.75 A_t S_p$; the bolt takes a share C of the external load: $F_b = F_i + CP$.
- Load factor $n = (S_p A_t - F_i)/(CP)$; the joint separates at $P_0 = F_i/(1 - C)$.
- **Spur gear** : $d = mN$ with **module** m; pitch-line speed $V = \pi dn/60$; $K_v = (6.1 + V)/6.1$ for cut teeth.
- Lewis bending: $\sigma = K_v W_t/(FmY)$, with the **Lewis form factor** Y.

Worked example. The flange bolts

M10 class 8.8: $A_t = 58.0$ mm^2, $S_p = 600$ MPa; $C = 0.25$, $P = 8$ kN per bolt.

- $F_i = 0.75 A_t S_p = 0.75 \times 58.0 \times 600 = \mathbf{26.1}$ kN.
- $F_b = F_i + CP = 26.1 + 0.25 \times 8 = 28.1$ kN, stress 484 MPa.
- $n = (S_p A_t - F_i)/(CP) = \mathbf{4.35}$; separation at $P_0 = 26.1/0.75 = \mathbf{34.8}$ kN.



2 Practice

2.1 An M12 class 8.8 bolt ($A_t = 84.3$ mm^2, $S_p = 600$ MPa) is preloaded to 75% of proof. Find the preload (one decimal, kN). [2]

2.2 The joint stiffness share is $C = 0.30$ and each bolt carries $P = 10$ kN. Find the bolt force (one decimal, kN), its stress (nearest MPa), the load factor (two decimals) and the separation load (one decimal, kN). [5]

3 Exam-style questions

3.1 A pinion of module 2.5 mm with 20 teeth ($Y = 0.322$) and face width 25 mm carries $T = 30$ N $\cdot$ m at 1200 rpm. Find its pitch diameter, tangential force, pitch-line speed, K_v and bending stress (one decimal, MPa). With an allowable 150 MPa, find the factor of safety and one way to raise it without changing the gear ratio. [7]